



DIP SWITCH 3	SW3	1	2	3	4	5	6	7	8
KEY B RATE	<b>A TYPE</b>	ON OFF ON OFF	ON ON OFF OFF	<b>B TYPE</b>					
	1 COIN 100 CREDIT			1 COIN 50 CREDIT					
	1 COIN 50 CREDIT			1 COIN 25 CREDIT					
	1 COIN 20 CREDIT			1 COIN 10 CREDIT					
	1 COIN 10 CREDIT	1 COIN 5 CREDIT							
COIN A RATE	1 COIN 10 CREDIT			ON	ON				
	1 COIN 5 CREDIT			OFF	ON				
	1 COIN 2 CREDIT			ON	OFF				
	1 COIN 1 CREDIT			OFF	OFF				
COIN D RATE	1 COIN 5 CREDIT	1 COIN 2 CREDIT			ON	ON			
	1 COIN 10 CREDIT	1 COIN 1 CREDIT			OFF	ON			
	1 COIN 20 CREDIT	2 COIN 1 CREDIT			ON	OFF			
	1 COIN 50 CREDIT	5 COIN 1 CREDIT			OFF	OFF			
COIN C RATE	1 COIN 1 CREDIT							ON	ON
	1 COIN 2 CREDIT							OFF	ON
	1 COIN 5 CREDIT							ON	OFF
	1 COIN 10 CREDIT							OFF	OFF

DIP SWITCH 4	SW4	1	2	3	4	5	6	7	8
HOPPER OUT BY COIN	YES	OFF							
	NOT	ON							
COIN IN LIMIT	20000		ON	ON					
	10000		OFF	ON					
	5000		ON	OFF					
	1,000		OFF	OFF					
NOT USED					OFF				
DEMO	YES					ON			
	NOT					OFF			
DOUBLE UP TYPE	BLACK & RED						ON		
	HI & LO						OFF		
SYMBOLS	PLANES							ON	
	CARDS							OFF	

DIP SWITCH 5	SW5	1	2	3	4	5	6	7	8
MINIMUM WIN	ANY PAIR	ON	OFF	OFF					
	6 OR BETTER	OFF	ON	OFF					
	10 OR BETTER	ON	ON	OFF					
	QUEEN OR BETTER	ON	OFF	ON					
	KINGS OR BETTER	OFF	ON	ON					
	2 PAIRS	OFF	OFF	OFF					
	ACES OR BETTER	ON	ON	ON					
JACKS OR BETTER	OFF	OFF	ON						
NOT USED					OFF				
NUMBER OF DRAWS	1					OFF			
	2					ON			
JOKER ON DECK	YES						ON		
	NOT						OFF		
MIN BET FOR PLAY	1							ON	ON
	20							ON	OFF
	10							OFF	OFF
	30							OFF	ON

### 72 Pin Game Logic Connector

COLOR	Part Side			Solder Side	Color
White/Red	Red Video	1	37	Green Video	White/Green
White/Blue	Blue Video	2	38	Video Sync	White /Yellow
Black/White	Speaker (+)	3	39	Video Ground	Black
Blue/White	Skill Stop	4	40		
Blue/White	Skill Stop	5	41		
Blue/White	Skill Stop	6	42		
White/Brown	Ticket Collect Switch	7	43		
Blue/Black	Ticket Notch Return	8	44		
Orange/White	Start Switch	9	45		
Green/White	Small Switch	10	46		
Violet/White	Bet Switch	11	47		
Blue/White	Take Score Switch	12	48		
Yellow/White	Double Up Switch	13	49		
		14	50		
		15	51		
Brown/White	Big Switch	16	52		
		17	53		
Gray/White	Coin Switch "A" Input	18	54	"Key In" Switch Input	White
Purple/Black	Coin Switch "C" Input	19	55	Coin Switch "D" Input	Red
White/Black	Test Switch	20	56	Confirm Switch	Blue
		21	57	Count Down Switch	White/Brown
Not Used	Hopper Full Switch	22	58	Hopper Count Switch	Not Used
Red/Black	Counter Output "A"	23	59		
Green/Black	Counter Output "B"	24	60		
Not Used	Counter Output "C"	25	61		
Green/Black	Counter Output "D"	26	62		
Not Used	Hopper Counter Output	27	63	Lack of Hopper Counter	
Red/White	Count down Meter Output	28	64		
Orange/Black	Start Lamp	29	65		
Green	Small Lamp	30	66		
Violet	Bet Lamp	31	67		
Blue	Take Score Lamp	32	68		
Yellow	Double Up Lamp	33	69		
Brown	Big Lamp	34	70		
		35	71		
Black	Switch Grounds	36	72	Switch Grounds	BLACK

**20 Pin Game PCB Power Connector**

<b>Color</b>	<b>Parts Side</b>			<b>Solder Side</b>	<b>Color</b>
Black	Logic Ground	1	11	Logic Ground	Black
Black	Logic Ground	2	12	Logic Ground	Black
Red	+5 VDC	3	13		
Red	+5 VDC	4	14	+5 VDC	Red
Orange	+12 VDC	5	15	+12VDC	Orange
		6	16		
White	Ticket Dispenser Enable	7	17		
		8	18		
Black	Logic Ground	9	19	Logic Ground	Black
Black	Logic Ground	10	20	Logic Ground	Black